


How to Measure for Your Blinds


Selecting and Measuring for “Inside” or “Outside Mount”:

Inside Mount: Blinds are mounted inside the window frame and window casing. Make sure your window casing has at least 1” of flat surface to mount the brackets inside.



Measurement for Inside Mounted Blinds: Measure the inside width of the window casing in 3 locations and choose the smallest measurement. **Then deduct $\frac{1}{2}$ ” from this measurement when ordering your blinds WIDTH.** For the Height simply measure the inside height of your window and order the exact height measured for the inside measurement.

Outside Mount: Blinds are mounted outside of the window frame and window casing, covering the entire window frame.



Measurement for Outside Mounted Blinds: Simply measure for the width of the exact outer dimensions that you want your blind to cover. For best results this should extend $\frac{3}{4}$ ” beyond the window opening on each side (or 1-1/2” for the entire width of the blind). For the Height also measure the height that you want the blind to cover. Then simply order the exact measurements for width and height desired when ordering your blinds.